

AJS-GZ-W1 Filling Machine



Instruction Manual

I. Main Specifications, Dimensions and Parameters

1. Main Specifications and Dimensions

| | |
|-------------------------|---|
| Machine Dimensions | Length 20inch*Width 21.6inch*Hight 47.2inch 500mm×550mm×1200mm |
| Maximum Cylinder Stroke | 3.93inch 100mm |
| Net Weight | 374LB(170kg) |
| Filling Mode | Upright filling |
| Production Capacity | 60-70 Cans/H |
| Applicable Scope | 330 ml / 500 ml Cans |

2. Technical Parameters

| | |
|---|-------------------------|
| Wine Source Pressure | 0.18~0.2MPA 26-29PSI |
| Air Source Pressure | 0.5-0.6 MPA 71.5-87PSI |
| CO ₂ Air Source Pressure | 0.3-0.4 MPA 43.5-58PSI |
| Cylinder Pressure Regulator | 0.4~0.45 MPA 58-65.3PSI |
| CO ₂ Counterbalance Valve Pressure | 0.18~0.2 MPA 26.1-29PSI |
| Compressed Air Regulator | 0.4~0.45 MPA 58-65.3PSI |

II. Operating Parts Introduction




Front



Right Side



Back



A. Filling machine model barcode.

B. Filling machine stop button: It can be selected to operate when problems occur during the filling process.

C. Filling machine operation touching screen, which will be introduced in detail later.

D. Filling machine filling head assembly.


E. Machine parts.

F. Filling machine power knob switch

G. Filling machine start button.

H. Filling machine 500ml can positioning base: Before use, select the positioning base corresponding to the can.

I. Filling machine 330ml can positioning base: Before use, select the positioning base corresponding to the can.





- J. Compressed air pressure regulator: The regulator is connected to compressed air source pipe. The compressed air pressure is shown as 0.4 MPA (58PSI).
- K. Compressed air pressure regulator: The regulator connects with compressed air source pipe. The compressed air pressure is shown as 0.2 MPA (29PSI).
- L. CO₂ counterbalance valve regulator: the regulator connects with CO₂ air source pipe. The CO₂ pressure is shown as 0.2 MPA (29PSI).
- M. Compressed air source connection interface: The air pipe with 10inch outside diameter is used to be firmly inserted into the interface, and the compressed air source pressure is 0.5-0.6 MPA (71.5-87PSI). It should be noted that the compressed air source pressure should not be lower than 0.4 MPA (58PSI) during the whole operation period of the machine.
- N. CO₂ air source connection interface: the air pipe with 10mm outside diameter is used to be firmly inserted into the interface, and the CO₂ pressure is 0.3-0.4 MPA (43.5-58PSI). It should be noted that the CO₂ source pressure should not be lower than 0.25 MPA (36.2PSI) during the use of the machine.

- O. Air pipe for connecting the wine source: Connect to the wine source with a soft air pipe with 12mm outside diameter. The wine source pressure should be kept between 0.2-0.22 MPA (29-31.9 PSI).
- P. Handle for pressure relief and regulating of filling: The adjustment of the handle valve can affect the filling speed and the production of beer foam. When the handle valve is adjusted to the right, the filling speed is slow, the pressure relief speed is slow and the filling capacity is reduced, so it is not easy to produce beer foam. When the handle valve is adjusted to the left, the filling speed is fast, the pressure relief speed is fast and the filling capacity will increase, but it is easy to produce beer foam. We have adjusted the handle valve and it is not recommended to make changes for it.
- Q. Power line: The machine adopts single 110V 60Hz power supply voltage.
- R. Touch screen introduction:



Touch Screen Initial Interface, with Chinese/English Options





Click  to enter the prompt interface



Then click  to enter the program selection interface. Suppose we need

to fill 500ml cans, click , and the color turns into green.  is the

Back button. Select  to enter the filling program setting interface of 500ml can, as follows:



This is the program setting interface of 500ml can, and relevant parameters can be modified by users. However, we have already set the parameters before delivery, and we do not recommend to modify them by users.

If 330ml cans need to be filled, the operation mode is the same as that of 500ml cans.

Note: This parameter should be set under the premise of 0.4 MPA (58PSI) of compressed air, 0.2 MPA (29PSI) of wine source and 0.2 MPA (29PSI) of CO₂. If any of the pressure values do not meet the requirements, the relevant parameters need to be adjusted, otherwise the ideal effect cannot be achieved.

III. Equipment Use

1. Check whether the connection of wine source and air source is correct and whether the pressure value of each pressure relief valve meets the specified requirements.
2. Turn on the power switch of the touch screen and select the filling program for the corresponding can.
3. Turn on the wine source switch, air source switch and CO₂ source switch.

4. Place the empty cans on the positioning plate.
5. Press the start button and the Filling machine will enter the pre-set program.

When the filling is finished, raise the filling head and just take off the can. Please check whether the pressure meets the requirements if the following phenomenon appears such as insufficient filling quantity, too much filling quantity or with beer foam. Due to the different quality of the beer made by different customers, the relevant parameters need to be adjusted appropriately according to the introduction of the operation manual. In addition, it should be noted that before filling the can, sufficient CO₂ pressure must be ensured in it, otherwise there will be beer foam.

Conduct filling operation.

IV. Equipment Maintenance

- 1) After daily work, clean the working table and close the wine source and air source.
- 2) Clean the whole machine at least once a day.