

OPERATION MANAUAL

1/2" -4" ELECTRIC PIPE
THREADING MACHINE



Catalogue

| | | |
|------|---|----|
| 1. | Instruction..... | 2 |
| 2. | Main Specifications and Parameters..... | 2 |
| 3. | Special Safety Requirement..... | 3 |
| 4. | Machine Structure..... | 5 |
| 5. | Operation..... | 6 |
| 5.1. | Unpacking..... | 6 |
| 5.2. | Transportation..... | 6 |
| 5.3. | Installation..... | 7 |
| 5.4. | Operation..... | 7 |
| 6. | Maintenance..... | 12 |
| 7. | Problem and Remedy..... | 13 |
| 8. | Section drawing of Main Parts..... | 14 |
| 8.1. | Body of Machine..... | 15 |
| 8.2. | Front Chuck/Rear Chuck..... | 16 |
| 8.3. | Gear Box..... | 17 |
| 8.4. | Die Head..... | 19 |
| 8.5. | Reamer Kit..... | 21 |
| 8.6. | Cutter Kit..... | 22 |
| 8.7. | Length Changing Apparatus..... | 23 |
| 8.8. | Cooling System..... | 23 |

I. Instruction

This machine is suitable for threading & cutting & beveling various of water, electricity and gas pipes with size of 1/2"-4". It is compact design, easy operation and high efficiency. Because with device of automatic threading & cutting taper thread of standard pipe, good clamping device and advanced cooling lubricant system, working life could be prolonged, pipe could be installed stably without deforming, as a result, machine could make high quality taper thread.

This machine could be widely used in equipment installation and construction industries and is an ideal equipment for improving efficiency, shortening process of construction, ensuring construction quality and decreasing manpower workload.

II. Main Specifications and Parameters

1. Capacity: 1/2"-4"
2. Applicable Threader Standard: BSPT / NPT
3. Die: 1/2" -3/4" one set
1" -2" one set
2 1/2" -4" one set
Rockwell Hardness: HRC58-62
4. Die Head: 1/2" -2" Automatic Die Head one set
2 1/2" -4" Automatic Die Head one set

5. Motor: YL7132, 14.5A, 2800RPM
6. Rotation Speed of axis: 28 RPM for 1/2"-2" threading
1/2"-4"cutting and beveling
12 RPM for 2 1/2"-4" threading
7. Output Power: 1100W
8. Max. Chuck Capacity: 124mm
9. Sledge Stroke: 150mm
10. Oil Feeder: gerotor oil pump, constant oil flow
11. Net Weight: 130Kg
12. Overall Dimensions: 950*560*520mm(without tubular supporters)

III. Special Safety Requirement

1. Keep the working site clean and bright(illumination condition 600lux) as disorder and darkness may cause accidents.
2. To avoid electric shock, do not expose the machine in the rain or operate it in moist workshop.
3. Operators should wear tight clothing, operators should remove gloves, jewelry, watch or likewise and should not loosen long hair.
4. When the threading machine(including its accessories) is installed in the working site, use the 30mA leakage resistance switch only.
5. The following is forbidden when the machine is running:
---Touching or grabbing the workpieces.

---Replacing or removing components(pipe accessories, valve or pipes etc.)

---Cutting or sawing pipes by hand tools

6. If the dangerous areas in the machine or its workpieces cannot be examined closely, the spinning workpieces or the dangerous areas should be protected. The protective devices must be reliably and stably placed. The supporting devices must be stable if they are used. Installing 4 pcs of tubular supporters and adjusting screws can ensure height and stability.

7. Keep children away when the machine is running, they are forbidden to operate the machine or drag the cable and wires.

8. Avoid overload operation, the unsuitable accessories, overload operation and blunt or damaged screwing die must not be used for fear that the machine would be damaged.

9. Extending too long pipes to operate the machine is forbidden. Keep this machine be balanced and stable all the time. Calculate the danger caused by suddenly-broken workpieces(based on the length of the workpieces, the section, the material and the rotate speed) and use enough supports to avoid danger.

10. Maintain this machine with care, lubricate the machine and replace the accessories according to the instruction of this manual operation to make the operation safer. Check the cables of the machine regularly . If there is any danger, it must be repaired by technician immediately. Keep various handles clean and tidy all the time. Keep them free of oil pollution.

11. Turn the power off. Pull the attaching plug out when the machine is not in

use.

12. Starting the motor carelessly is forbidden, make sure the switch is at the position of “off” before the plug is connected with the machine.

13. Do not operate the machine when the operator is tired, or if he has used any drugs.

14. Check the damaged spare parts, check any cutting tools and parts carefully before using them, and see if they are in normal working condition and function. Any damaged parts must be repaired and replaced by professional technicians.

15. Operation is forbidden when any switch can not be properly turned on or off.


16. Replacing parts and accessories: use the parts of SHIDA Electric Threader for safety and proper operation.

IV. Machine Structure

Main parts of this machine is made of high-strength aluminum alloy and high-quality cast iron, as a results, machine is lighter and high strength. Outside structure please refer to below drawing.

Die Head, Reamer Cutter Kit and Cutter Kit are all installed on sledge of machine, and sledge could be moved longitudinally.

Electrical motor, Gearbox and cooling oil pump are set inside of machine body.



V. Operation

1. Unpacking:

When unpack the case, check if the following accessories are enclosed

- ① One barrier of cutting oil (2.5L)
- ② Two sets of Threading Die packed in plastic box(4 pcs each set).
- ③ One set of Automatic Type Die Head
- ④ Four piece of tubular supporter.
- ⑤ Tools (one set of Hexagon Inner Spanner/ 1 Screw Driver/ 1 wrench)
- ⑥ Dope Can

2. Transportation:

Fix the Die Head at the position of threading, and open all dies thoroughly, put a short pipe in Front Chuck tightly, and put Cutter Kit on the pipe, and also Reamer Cutter Kit is fixed on the position of reaming, hence machine could be transported.

3. Installation:

- ① Put all accessories aside and install 4 pcs of tubular supporters into the hole at the bottom of machine.
- ② Fasten it with screws safely and reliably.
- ③ When install the machine, length of 4 pcs of tubular supporters should be adjusted to ensure that Rear Chuck is a little higher than Front Chuck. And the pipe put in the Front Chuck have to be removed, and re-put when next transportation.

4. Operation

4.1. Preparation for Threading

- ① Replacing Die

a. There are three sets of Dies, each of which threads different pipes, as below:

| Pipe | Die |
|-----------|-----------------------------|
| 1/2"-3/4" | 1/2"-3/4" 11.5 threads/inch |
| 1"-2" | 1"-2" 11.5 threads/inch |
| 2 1/2"-4" | 2 1/2"-4" 8 threads/inch |

Choose a set of that matches the diameter of pipe. There are two groups of figures on each die, one of which represents its specification, the other represents the assemble sequential numbers, such as 1,2,3,4.

b. Remove the Die Head from sledge(Fig. 1), loosen the nut of handle, and turn the curve plate around to the maximal position of the scale.

c. Put the selected Dies into die grooves according to their sequential numbers, and its lock notch will fit curve plate. Then pull the curve plate until the Scale Indicator of the curve plate points at the scale on the ruler of the job. Then the

die is fixed.

Note: 1/2"-3/4" & 1"-2" Dies are installed in small Die Heads, while 2 1/2"-4"

Die is installed in big one.




Fig.1

Fig. 2

d. Place the assembled Die Head on the Sledge.

②Checking cutting oil

- a. Check whether there is enough cutting oil in the tank.
- b. Add oil when needed through the oil filling opening.
- c. Cutting oil will overflow over the Die Head after the machine runs.

Note: use cutting oil only to ensure to produce high-quality threads.

③Threading Operation

- a. Any operation requiring non-rotating condition should be done only when the machine stops running.
- b. Loosen Front & Rear Chuck.
- c. Hold the pipe by hand, tighten the Rear Chuck firstly, then tighten the Front Chuck to fix the pipe, then beat the Hammer Disk in counter clockwise to be tight, hence the pipe is clamped well.




Fig.3

d. If pipe could not reach the Rear Chuck when threads short pipe, to loose little the Front Chuck, put short pipe in and make it touch the Die, which is good for ensuring the pipe is in the central position when tighten the Front Chuck. Pls refer to the Fig.4.




Fig.4

e. Pull up the Cutter Kit and Reamer Cutter Kit to make room, then push down the Die Head, make it to touch the Profiling Board(see Fig.6), and lock it tight with locking pin. Push the button switch to start the machine after the Die Head is fixed on its proper position.




Fig.6

Caution: To keep the machine run in order, Gear Shift Hand should be place at the position of bottom gear when threading pipes with diameter bigger than 2 inches, otherwise, place the Gearshift Handle at the position of top gear (See Fig.7).




Fig. 7




Fig.8

f. The pipe must rotate in counter clockwise, then rotate the sledge handle to move the Die Head to the pipe.

g. Apply force on the sledge handle wheel until 3-4 threads are made on the pipe.

h. Stop applying force. The machine begins to thread automatically until the roller of Die Head passes the Profiling Board and falls down.

Caution: Two steps should be followed when threading pipes with diameter bigger than 2 inches. Firstly, place the Size scales one scale lower than the scale required; secondly, make the scale indicator point to the scale required.

i. Stop the machine and quit the Die Head to the right unused position.

j. Loosen the Front and Rear Chucks clockwise, and remove the pipe from Rear Chuck.

④ Cutting the pipe

- a. Pull up Die Head and Reamer Cutter Kit, make Front Chuck and Rear Chuck fasten pipe well.
- b. Push down the Cutter Kit, and rotate the handle to open the rack to let the cutting wheel touch the pipe.
- c. Rotate sledge handle to move the cutter kit to cutting position(See Fig.9).




Fig.9

- d. Rotate the handle to move the cutter wheel to touch the pipe.
- e. Start the machine. Switch the Gearshift Hand to the top gear and make the cutting wheel cut into the pipe. Cut about 0.15-0.25mm for one turn of the pipe, i.e. for each turn of the basic shaft the handle forwards about 1/10 turn. Quit the cutter wheel and pull up the Cutter Kit to its un-working position after cutting.

Caution: Cut with moderate speed and force to avoid distortion of pipe and damage to the wheel.

⑤ Inner Wall Beveling

- a. Pull up the Die Head and Cutter Kit and push down the Reamer Cutter Kit, make the Front Chuck and Rear Chuck fasten the pipe well.
- b. Start the machine. Move the Gearshift Hand to the top gear, rotate the sledge handle wheel and drive the Reamer Cutter Kit to the inside of pipe(See Fig.10)




Fig.10

c. Stop the machine after beveling, and move the Reamer Cutter Kit to its un-working position.

VI. Maintenance

1. Turn the master switch to the position of“OFF”, or unplug the power when machine is checked and maintained.
2. Shell of machine is cast with a whole piece of aluminum alloy, its reduction gearbox keeps lubricating permanently. Do not impact the shell violently.
3. Cooling oil system: clean the oil filter disk and oil suction filter disk after running for 8-12 hours. Clean the oil tank and refill it if the oil inside is dirty or turns black.
4. Small iron filings may fall into the oil tank when threading, it is therefore essential to clean the filter disk once a week to keep the machine in order.
5. Check the cutter wheel each once a week, replace it when it is blunt.
6. Check the attrition of the Chuck Jaw Inserts once a month. If the Chuck Jaw Inserts are worn, replace them(three each set) to ensure to produce threads of high quality.

7. Clean Die Head and Die every shift. Check if the teeth of Die are broken, if they are, remove the cuttings between teeth; if the Die has already been broken, replace a set of Die instead of the broken one.

8. There are two oil cups on the shell of main shaft, oil at least twice each shift to be lubricated the fore and rear bearing.

9. Unplug the power when the machine is not in use, coat corrosion resistant oil on both fore and rear guideposts and other working surface. Store it in dry ventilated place.


VII. Problem and Remedy

| Problem | Cause | Remedy |
|---|---|--|
| The motor doesn't run or makes breaking sounds when running | The fuse is blown | Replace the fuse |
| | A poor power contact | Replace the plug wire |
| | The insides of the cable is broken | Locate the point broken with multimeter |
| | Electric capacity is broken down | Replace the electric capacity |
| The pipe can't be fastened or it slips when threading | Less forceful stroke | Hammer with force |
| | The chuck jaw insert is upside-down | Adjust the chuck jaw insert |
| | One of chuck jaw inserts is broken or notch-edged | Replace the chuck jaw inserts |
| The cutting knife can't cut | The point of cutting knife is worn-out and not sharp | Replace the blade |
| | The pin roll of cutter knife is worn down | Replace the pin roll |
| | Apply less force when starting cut | Cut with force |
| The cutting knife doesn't work when threading | The knife doesn't open widely when starting to thread | Use the knife properly |
| | A few teeth of the cutter head are broken | Replace the knife |
| | The type and size of the knife is not suitable | Reinstall the knife |
| | There are iron filings in the groove | Clean the Die Head |
| The Front Chuck body is loose | M6 bolts are loose for long-term use | Check at all times |
| The main shaft heats up | Lack of oil | Oil regularly |
| | | Remove the beam barrel and scratch the shaft |

| | | |
|---|---|---|
| The cooling oil can not be sufficiently provided | The oil circuit is blocked | Clean the oil circuit |
| | The oil hole is not installed properly after the fulcrum shaft of the Die Head is removed | Reinstall it |
| | The oil in oil pump has leaked out | Fill some cooling oil in the oil pump |
| The cooling oil leaks into the motor | The oil seal of the oil pump PD8x22x8 has been damaged | Replace the oil seal |
| The threads are deflected | The pipe is curved too much or out of round | Select appropriate pipe |
| | The long pipe isn't supported by support | Equip with supporter |
| | There is extra substance in the chuck jaw insert | Remove extra substance |
| | One of the chuck jaw insert is broken or notch-edged | Replace the chuck jaw insert |
| The threads are shapeless and the threads are thin instead of thick | The rigidity of the pipe is slightly higher | Select appropriate pipe |
| | The outer diameter of pipe is too bigger | Select appropriate pipe |
| | The cutting edge of pipe is out of vertical | Machining it vertical |
| | The carriage moved hard | Find out the reason and modify |
| | The order of Die doesn't match the groove | Correct the order of Dies |
| | The gap of Die Head is too wide | Repair or replace the Die Head |
| The surface of threads is not perfect | Process with high speed | Process with low speed |
| | The dies are blunt | Change the die |
| | The oil isn't infused | Use cutting oil |
| Can't change speed | The middle clutch in the gearbox is worn | Replace the middle clutch and repair the gear |
| | The connecting pin is broken | Replace a new one |

VIII. Section Drawing of Main Parts


1. 40100 Body of Machine



| Item | Code | Name | Qty | Remark |
|------|-------|------------------------------|-----|------------|
| 1 | 40101 | Seating | 1 | - 0001 |
| 2 | 40102 | Head Stock | 1 | - 0002 |
| 3 | 40103 | Bearing | 2 | - 0003 |
| 4 | 40104 | Gearshift Handle | 1 | -0004 |
| 5 | 40105 | Sledge | 1 | -0005 |
| 6 | 40106 | Shaft gear of handle wheel | 1 | -0006 |
| 7 | 40107 | Data plate | 1 | - 0003 |
| 8 | 40108 | Front lead screw | 1 | - 0009 |
| 9 | 40109 | Rear lead screw | 1 | - 0010 |
| 10 | 40110 | Chip pan | 1 | - 0005 |
| 12 | 40112 | Pull knob | 1 | -0015 |
| 13 | 40113 | Cover of oil filling opening | 1 | -0016 |
| 14 | 40114 | Cover | 2 | -0018 |
| 15 | 40115 | Handle wheel | 1 | - 0018 - 1 |
| 16 | 40116 | Handle spindle | 1 | -0008 - 2 |
| 17 | 40117 | Tubular supporter | 1 | -0006 |
| 18 | 40118 | Circlip | 1 | -0009 |
| 19 | 40119 | Lock tongue | 1 | -0011 |
| 20 | 40120 | Lock stem | 1 | -0012 |
| 21 | 40121 | Spring | 1 | -0013 |

| | | | | |
|----|-------|--------------------------------|---|--------------------|
| 22 | 40122 | Bolt sleeve | 1 | -0014 |
| 25 | 40125 | Slotted cap screw M5X10 | 2 | GB67-85 |
| 26 | 40126 | Hex. Socket head screw M10X70 | 4 | GB70-85 |
| 27 | 40127 | Hex. Socket holding screw | 6 | GB77-85 |
| 28 | 40128 | Slotted cap screw M4X14 | 2 | GB67-85 |
| 29 | 40129 | Slotted cap screw M4X8 | 3 | GB67-85 |
| 30 | 40130 | Square head holding screw | 4 | GB85-88 |
| 31 | 40131 | Spring washer Φ10 | 4 | GB93-86 |
| 32 | 40132 | Rivet of Gearshift Handle 3X15 | 2 | GB827-86 |
| 33 | 40133 | Rivet of data plate 3X15 | 4 | GB827-86 |
| 34 | 40134 | Flexible round pin 6X35 | 1 | GB879-87 |
| 36 | 40136 | Cable clamp | 1 | -0118 |
| 37 | 40137 | Button switch | 1 | K _{AO} -5 |
| 39 | 40139 | lifter | 2 | -0004 |


2. 40200 / 40222 Front Chuck/ Rear Chuck



| Item | Code | Name | Qty | Remark |
|------|-------|-------------|-----|--------|
| 1 | 40201 | Chuck plate | 1 | -0601 |

| | | | | |
|----|-------|--------------------------|---|------------|
| 2 | 40202 | Chuck jaw inserts | 3 | - 0604 |
| 3 | 40203 | Chuck haws | 3 | - 0603 |
| 4 | 40204 | Big screw caliper | 1 | - 0608 |
| 5 | 40205 | Supporting screw | 3 | - 0606 |
| 6 | 40206 | Stock foot | 3 | - 0605 |
| 7 | 40207 | Spring | 3 | - 0607 |
| 8 | 40208 | Hammer disk | 1 | - 0602 |
| 9 | 40209 | Big gear | 1 | - 0027 - 2 |
| 10 | 40210 | Hollow spindle | 1 | - 0027 - 1 |
| 12 | 40212 | Washer | 1 | - 0705 |
| 13 | 40213 | Rear chuck jaw | 3 | - 0704 |
| 14 | 40214 | Back plate of rear chuck | 1 | - 0702 |
| 15 | 40215 | Small screw caliper | 1 | - 0703 |
| 16 | 40216 | Hex. socket screw M6X14 | 3 | GB70 - 85 |
| 17 | 40217 | Hex. socket screw M8X55 | 6 | GB70 - 85 |
| 18 | 40218 | Round pin 8X20 | 1 | GB119 - 86 |
| 19 | 40219 | Hex. socket screw M8X25 | 3 | GB70 - 85 |
| 20 | 40220 | Φ180 circlip | 1 | |
| 21 | 40211 | Spring washer M8 | 3 | GB93 - 87 |

3. 40300 Gearbox




| Item | Code | Name | Qty | Remark |
|------|-------|------------------------------|-----|----------------|
| 1 | 40301 | Body | 1 | - 0518 |
| 2 | 40302 | Cover | 1 | - 0518 |
| 3 | 40303 | Motor gear | 1 | - 0501 |
| 4 | 40304 | Oil seal | 1 | HG4 - 692 - 67 |
| 5 | 40305 | Bearing 6002 | 1 | GB276 - 64 |
| 6 | 40306 | High-speed gear | 1 | - 0502 |
| 7 | 40307 | High-speed gear spindle | 1 | - 0503 |
| 8 | 40308 | Bearing 6002 | 1 | GB276 - 64 |
| 9 | 40309 | Cover | 3 | - 0502 |
| 10 | 40310 | Oil pump seat | 1 | - 0526 |
| 11 | 40311 | Bearing 6003 | 1 | GB276 - 64 |
| 12 | 40312 | 2# gear spindle | 1 | - 0504 |
| 13 | 40313 | Flat key 5X12 | 3 | GB1096 - 97 |
| 14 | 40314 | Bull gear of 2# gear spindle | 1 | - 0504 |
| 15 | 40315 | Bearing 6202 | 1 | GB276 - 64 |
| 16 | 40316 | Cover | 1 | - 0529 |
| 17 | 40317 | Socket screw M5X16 | 6 | GB70 - 86 |
| 18 | 40318 | Cover | 1 | - 0528 |
| 19 | 40319 | Bearing 6203 | 1 | GB276 - 64 |
| 20 | 40320 | Bull gear of 3# gear spindle | 1 | - 0506 |
| 21 | 40321 | Flat key 5X12 | 2 | GB1096 - 79 |
| 22 | 40322 | 2# gear spindle | 1 | - 0508 |
| 23 | 40323 | Pinion of 3# gear spindle | 1 | - 0507 |
| 24 | 40324 | Bearing 6203 | 1 | GB276 - 64 |
| 25 | 40325 | Cover | 1 | - 0528 |
| 26 | 40326 | Cover | 1 | - 0528 |
| 27 | 40327 | Bearing 6203 | 1 | GB276 - 64 |
| 29 | 40329 | High-speed gear | 1 | - 0529 |
| 30 | 40330 | joint | 1 | - 0512 |
| 31 | 40331 | sleeve | 1 | - 0514 |
| 32 | 40332 | Low-speed gear | 1 | - 0513 |
| 33 | 40333 | Anti-extrusion ring | 1 | - 0515 |
| 34 | 40334 | Bearing 6205 | 1 | GB278 - 64 |
| 36 | 40336 | Output gear spindle | 1 | - 0516 |

| | | | | |
|----|-------|---------------------------------|----|-----------|
| 39 | 40339 | Button-headed screw M5X6 | 10 | GB67 – 66 |
| 40 | 40340 | Shifting yoke | 1 | – 0519 |
| 41 | 40341 | Connecting rod of gearbox | 1 | – 0511 |
| 42 | 40342 | Axle seat of shifting yoke | 1 | – 0522 |
| 43 | 40343 | Declutch shift shaft of gearbox | 1 | – 0523 |
| 44 | 40344 | Speed-regulating hand wheel | 1 | – 0501 |
| 45 | 40345 | Socket screw M8X55 | 1 | GB70 – 86 |

4. 40400 Die Head

40400(A) 1/2"-2" Die Head

40400(B) 2 1/2"-4" Die Head




| Item | Code | Name | Qt | Remark |
|------|------|------|----|--------|
|------|------|------|----|--------|

| | | | | |
|----|-----------------------|--|---|----------------------------------|
| 1 | 40401(A) 40401(B) | Curve plate A (small) B (big) * | 2 | - 0102 ^A _B |
| 2 | 40402(A) 40402(B) | Front plate A (small) B (big) * | 2 | - 0103 ^A _B |
| 3 | 40403(A) 40403(B) | Rear plate A (small) B (big) * | 2 | - 0101 ^A _B |
| 4 | 40404(A) 40404(B) | Backing ring A (small) B (big) * | 2 | - 0104 ^A _B |
| 5 | 40405 | Hex. Socket holding screw M6X15 | 1 | GB78 – 85 |
| 6 | 40406 | hoodle | 8 | |
| 7 | 8002 8003 80011 | Die $\frac{1}{2} \sim \frac{3}{4}$ 、 $1 \sim 2$ 、 $2\frac{1}{2} \sim 4$ | 3 | - 0107 |
| 8 | 40408 | Pinching screw | 2 | - 0110 |
| 9 | 40409 | Support shaft | 2 | - 0108 |
| 10 | 40410 | Hex. Socket holding screw M12X12 | 2 | GB78 – 85 |
| 12 | 40412(A) 40412(B) | Size scales A($\frac{1}{2}$ "~2")B($\frac{1}{2}$ "~4") | 2 | - 0111 ^A _B |
| 13 | 40413 | Washer | 2 | -0106 |
| 14 | 40414 | Handle | 2 | -0105 |
| 15 | 40415 | Dowel pin | 2 | -0109 |
| 16 | 40416 | Roller wheel | 2 | -0112 |
| 17 | 40417 | Inner pul-out piece spring (40400A Die Head only) | 1 | -0113 |
| 18 | 40418 | Slotted cap screw M4X8 | 4 | GB67 – 85 |
| 19 | 40419 | Hex. Nut M10 (thin) | 2 | GB170 – 86 |
| 20 | 40420 | Hex. Socket holding screw M8X10 | 2 | GB78 – 85 |
| 21 | 40421 | Hex. Socket holding screw M6X35 | 8 | GB70 – 85 |
| 22 | 40422 | Column pin 6X25 | 2 | GB119 – 86 |


- Die Head(big) is 2 1/2"-4"; Die Head(small) is 1/2"-2"

5. 40500 Reamer Kit




| Item | Code | Name | Qty | Remark |
|------|-------|-------------------------|-----|----------|
| 1 | 40501 | Blade | 1 | - 0301 |
| 2 | 40502 | Holder of reamer cutter | 1 | - 0302 |
| 3 | 40503 | Shaft of reamer cutter | 1 | - 0303A |
| 4 | 40504 | Handle | 1 | - 0304 |
| 5 | 40505 | Axle pin | 1 | - 0305 |
| 6 | 40506 | Flexible round pin 8X50 | 1 | GB879-86 |
| 7 | 40507 | Flexible round pin 4X12 | 1 | GB879-86 |
| 8 | 40508 | Key | 1 | - 0306 |

6. 40600 Cutter Kit




| Item | Code | Name | Qty | Remark |
|------|-------|-------------------------|-----|------------|
| 1 | 40601 | Cutter handle | 1 | - 0201 - 1 |
| 3 | 40602 | Cutter holder | 1 | - 0203 |
| 4 | 40603 | Roller holder | 1 | - 0202 |
| 5 | 40604 | Cutter seat frame | 1 | - 0204 |
| 6 | 40606 | Dowel pin | 1 | - 0211 |
| 7 | 80606 | Cutting wheel | 1 | - 0210 |
| 8 | 40607 | Rollers | 4 | - 0208 |
| 9 | 40609 | Axle pin | 5 | - 0209 |
| 10 | 40610 | Long idler | 1 | - 0206 |
| 11 | 40611 | Feed screw | 1 | - 0205 |
| 12 | 40612 | Short idler | 1 | - 0207 |
| 13 | 40613 | Pin 3X19 | 5 | GB91 - 86 |
| 14 | 40614 | Flexible round pin 6X35 | 5 | GB897 - 86 |
| 15 | 40615 | Bearing 8103 | 1 | GB301 - 64 |

7. 40700 Length Changing Apparatus



| Item | Code | Name | Qty | Remark |
|------|-------|---------------------------|-----|----------|
| 1 | 40701 | Front anti-extrusion ring | 1 | - 0402 |
| 2 | 40702 | Axle | 1 | - 0411 |
| 3 | 40703 | Body frame | 1 | - 0401 |
| 4 | 40704 | Distance plate | 1 | - 0402 |
| 5 | 40705 | Dust proof cover | 1 | - 0405 |
| 6 | 40706 | Profiling board | 1 | - 0401 |
| 7 | 40707 | Spring | 1 | - 0406 |
| 8 | 40708 | Rear anti-extrusion ring | 1 | - 0403 |
| 9 | 40709 | Bearing spring | 2 | - 0408 |
| 10 | 40710 | Size plate | 1 | - 0409 |
| 11 | 40711 | Length changing indicator | 1 | - 0407 |
| 12 | 40712 | Spring | 1 | - 0413 |
| 13 | 40713 | Displacing plate | 1 | - 0410 |
| 14 | 40714 | Steel ball 5mm | 1 | GB308-77 |

8. 40800 Cooling system



| Item | Code | Name | Qty | Remark |
|------|-------|---------------------------------|-----|-------------|
| 1 | 80801 | Oil pump | 1 | - 0801 |
| 2 | 40802 | joint | 3 | - 0808 |
| 3 | 40803 | Oil-filter | 1 | - 0809 |
| 4 | 40804 | Oil pipe | 1 | - 0810 |
| 5 | 40805 | Throttle valve handle | 1 | - 0811 |
| 6 | 40806 | Throttle valve body | 1 | - 0812 |
| 7 | 40807 | Throttle valve core | 1 | - 0813 |
| 8 | 40808 | Spring | 1 | - 0814 |
| 9 | 40809 | Pipe joint | 1 | - 0815 |
| 10 | 40810 | Angle fittings | 1 | - 0816 |
| 11 | 40811 | Short oil pipe | 1 | - 0817 |
| 12 | 40812 | Oil overflowing pipe | 1 | - 0818 |
| 13 | 40813 | Oil draining pipe | 1 | - 0819 |
| 14 | 40814 | Column pin 3X24 | 1 | GB119-86 |
| 15 | 40815 | Hex. Socket holding screw M5X10 | 1 | GB78-85 |
| 16 | 40816 | ○ type lock ring 13X1.9 | 1 | GB3452.1-82 |
| 17 | 40817 | Slotted cap screw M4X10 | 1 | GB67-85 |
| 18 | 40818 | ○ type lock ring 33X2.65 | 1 | GB3452.1-82 |
| 19 | 40819 | Oil-proof rubber hose | 2 | |
| 20 | 40820 | Skeleton type rubber oil seal | 1 | HG4-692-67 |
| 21 | 40821 | Circlip for hole Φ22 | 1 | GB893.1-86 |
| 22 | 40822 | Screw of oil tank | 1 | |