How to replce the controller

1. Pls take off the battery wire.

2. Pls release the rest electricity before unplugging them.
pls see the video that how to release, (Becuase as long as we used the controller, there are electricity inside.)

3. there are two motor wires in the controller,



4. find the arrow to connect.
If you feel it is a little hard to plug the wire, it means two wires does not match correctly.



