







# Assembling Instructions


## For 10x20 foot Tent (3x6m)

#1	1960mm 	foot pole	8pcs	B		4-connector	6pcs
#2	1670mm 	roof pole	8pcs	D		Nylon cable ties	50pcs
#3	1930mm 	roof pole	9pcs				
A		3-connector	6pcs				

1. Before install your tent please prepare gloves to Avoid the anti-rust oil on the tubes surface.
2. Recommended to have 2-3 people to assemble tent to avoid damage
3. Now completely unpack tent from all boxes and inspect all pieces compare to above parts list


### Step 1 Assembly of roof structure

- Use tube #2 and #3, connector A and B to set up the roof structure
- Need to make sure that the hole in the longer end of the connector is pointed downward for connection to the foot pole




### Step 2 Cover the canopy

- unfold canopy and put over roof frame structure
- use nylon cable ties "D" to connect canopy and frame on front and back, when the tent stand up, both roof sides are too high to reach



### Step 3 Set up the tent

- with a person at each pole connector on one side of the roof structure, lift the roof structure and insert #1 pole into the pole connector, allow structure to be supported by the foot poles. Move to the opposite side of the roof structure to install other foot poles.
- To secure the roof cover with nylon cable ties “D”



### Step 4 Install sidewalls as needed (If you purchased a model with side walls)

