










Assembling Instructions


For 20x30 foot Tent (6x9m)

#1	1870mm 	foot pole	10pcs	B		4-connector	9pcs
#2	1870mm 	roof pole	10pcs	C		Earth pin	28pcs
#3	1325mm 	roof pole	10pcs	D		Nylon cable ties	200pcs
#4	2095mm 	roof pole	12pcs	E		Rope 8m	4pcs
A		3-connector	6pcs				

1. Before install your tent please prepare gloves to Avoid the anti-rust oil on the tubes surface.
2. Recommended to have 4-6 people to assemble tent to avoid damage
3. Now completely unpack tent from all boxes and inspect all pieces compare to above parts list

Step 1 Assembly of roof structure

- Use tube #2, #3, #4, connector A and B to set up the roof structure
- Need to make sure that the hole in the longer end of the connector is pointed downward for connection to the foot pole
- #3 poles are shrinkable on one end, the shrinkable end should connect with connector A or B, and one side of #2 pole should slide into the #3 pole, and the other side of #2 pole connect with connector A or B.




Step 2 Cover the canopy

- unfold canopy and put over roof frame structure
- use nylon cable ties "D" to connect canopy and frame on front and back, when the tent stand up, both roof sides are too high to reach



Step 3 Set up the tent

- with a person at each pole connector on one side of the roof structure, lift the roof structure and insert #1 pole into the pole connector, allow structure to be supported by the foot poles. Move to the opposite side of the roof structure to install other foot poles.
- To secure the roof cover with nylon cable ties “D”
- To secure the tent with earth pins “C” in each foot poles and ropes in 4 corners of the tent



Step 4 Install sidewalls as needed

