

## I III **@=** O Socket wrench Step-2: Select suitable screws from the screw TV package according to the size of the holes in the back of TV, then install the TV to the front plate. Step-3: Two people hang the TV Plate with the TV Set onto the arm connect part and screw tighten at last. ΤV 15 0 0-00 ) Je el i Step-4: Loosen the screw to adjust the angle of the TV between +5 and -15 degree to a suitable position, and then fix the screw firmly. +5°

-15

TV