


## Double convection oven stacking kit instruction



1、 Open the carton, and you can see all the parts of double convection oven stacking kit.






2、 Remove the 4 screws from roof of the bottom oven body (two screws of these need open the control panel, remove the nuts inside ), and install the spacer plate









3、 Install the 6"caster, two caster with brake fit on the front of the oven, and other two caster without brake fit on the second half of the oven.







4、 Remove the small single exhaust flues from top and bottom oven.



5. Remove the bolts from the bottom of the left and right plate of the bottom oven and remove the burner box. Then lift the top oven up with the hand fork lift truck.









6、 Stack the top oven on the roof of the bottom oven, and install the L plate and the burner box.





...SYSTEMS, IT MUST BE INSTALLED WITH  
THE CASTERS SUPPLIED. A CONNECTOR COMPLYING  
WITH ANSI Z21.89 - CSA 6.16 AND A QUIET  
DISCONNECT DEVICE COMPLYING WITH ANSI  
Z21.41 - CSA 6.9. IT MUST ALSO BE INSTALLED  
WITH RESTRAINING MEANS TO GUARD AGAINST  
TRANSMISSION OF STRAIN TO THE CONNECTOR,  
AS SPECIFIED IN THE APPLIANCE MANUFACTURER'S  
INSTRUCTIONS.

**⚠ ATTENTION**  
AVIS: LES APPAREILS SUR ROULETTES  
DOIVENT ÊTRE POURVUS DES ROULETTES FOURNIES D'UN  
TUYAU DE RACCORDEMENT CONFORME À LA NORME  
ANSI Z21.89 - CSA 6.16 ET D'UN RACCORD  
À DÉBRANCHEMENT RAPIDE SATISFAISANT LES EXIGENCES  
DE LA NORME ANSI Z21.41 - CSA 6.9. ILS DOIVENT  
AUSSI ÊTRE MUNIS D'UN DISPOSITIF DE RETENUE POUR  
EMPÊCHER TOUTE TRANSMISSION DE TENSION AU  
TUYAU DE RACCORDEMENT CONFORMEMENT AUX  
INSTRUCTIONS DU FABRICANT.


**WARNING**  
READ INSTRUCTIONS

**ATTENTION**











7、 Install the connection plate and the double deck hood with screws on the back of the double oven.







8、 The double convection oven installation complete.

