
10'x10' Gazebo Lowell

Owner's Manual

OUTDOOR PATIO GAZEBO

MODEL #HFZP02027



Q Assemble Tips

1. Secure the assembly area. Keep children and pets away from the assembly area.

2. It is recommended that two or more adults are involved, to assemble the pergola.

3. Ensure that all connectors & poles are firmly secured in position fully. A unstable gazebo may collapse or damage unpredictability.

Extremely Weather

1. Do not leave the gazebo assembled when there is a risk of high wind, the top cloth may be blown away and the structure may be damaged.

2. Do not use the gazebo during an electrical storm.

3. Warranty does not cover damage due to extreme weather conditions.

🙆 Fire Caution


1. Do not use candles, matches or open flames of any kind in or near.

2. Keep all flame and heat source away from this Tent Fabric. This tent is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source.

☑ Contact Us

If you have any comments or suggestions, Please feel free to contact us.

Service@hofzelt.com



HARDWARE CONTENTS

No.	DESCRIPTION	Draft	QTY	EXTRA
AA	M6x20 Bolt		8	1
BB	Washer		72	4
СС	M6x30 Bolt		32	2
DD	Nut		8	1
EE	M6x35 Bolt		8	1
Z	Wrench		2	0
FF	Stake		16	0
GG	Plastic Ring		48	3
КК	Plastic Cap		16	1

PACKAGE CONTENTS

No.	DESCRIPTION	Draft	QTY
A1	Upper of Big Screen		4
A2	Bottom of Big Screen		4
A3	Upper of Small Screen		4
A4	Bottom of Small Screen		4
B1	Pole 1 to Connect Screens	<>>	4
B2	Pole 2 to Connect Screens	<u>♦ • }, </u>	4
D1	Up of Middle Beam	e	4
D2	End of Middle Beam		4
E	Connector of Corner Beam		4
F	Adjustable Beam for Small Top	booo	4
н	Up of Corner Beam		4
H1	End of Corner Beam	ee	4
к	Big Top Connector		1
L	Hook		1
м	Big Canopy		1
N	Small Canopy		1
0	Mosquito Netting		1
U	Side Wall		1

