



Button switch on the lamp cap



6006      6006F      202F

Button switch on the power line



6006A      6047      6000      6008



Switch on the lamp head



40F-C      40F-D      50F      30F

# Installation Notes



Four hole fixing holder  
Mounting hole distance 45 mm.  
Hole diameter 5 mm. Screw size M5×16



Switch magnet holder  
"ON" is to open the magnet;  
"OFF" is to turn off the magnet.



Metal clip lamp holder  
The maximum clip thickness is 55 mm



Large three-hole fixed lamp holder  
Mounting hole distance 60 mm.  
Hole diameter 5 mm.



Round magnet holder  
It can directly adsorb metal to  
complete the installation.



Small three-hole fixed lamp holder  
Mounting hole distance 30 mm.  
Hole diameter 3 mm.



Large four-hole fixed lamp holder  
Mounting hole distance 60 mm.  
Hole diameter 7 mm.



Large round magnet holder  
It can directly adsorb metal to  
complete the installation.



Small two-hole fixed lamp holder  
Mounting hole distance 25 mm.  
Hole diameter 4 mm.

## Precautions for use:



Please pay attention to the safety of electricity; the voltage of the lamp can be seen on the label of the lamp;

**The 24V should not be connected to the 220V.**

The lamp voltage and socket voltage can not be used when it is different, otherwise it will be dangerous.

**24V can only be connected to 24V, 220V can only Connected to 220V.**