




Instructions




1. folded state




2. Lift up




3. Press the thumb in




4. hands out short plate




8. Sway Back And Forth



7. Hold Up



6. Hangs Clapped Shot Board



5. Open state

- 1, Please make sure all the parts in the right position when unfold it.
- 2, Children under 3 years old are required to use it by adult assistance.
- 3, Do not expose to the burning sun.
- 4, Do not overloading or hold any water.
- 5, Environmental request : -4°F to 149°F