



1. Control case
2. Electric warming wire, silicon bar
3. Work table
4. Supportor
5. Peer-step

TG Pedal Impulse Sealing Machine

Manual

Passable pedal Impulse Sealing Machine

Cautions:

This machine is electric technical product, which should be kept in dry area. When in use, the voltage should be in conformity with the AC220V standard. No flammable or explosive thing is allowed to be put on the sealing mouth of this machine. Do not touch the heating parts of this machine when the machine is working.

Introduction

Passable pedal Impulse Sealing Machine was improved from Pedal Impulse Sealing Machine. After this improvement, this machine is well devised with steady working.

The advantage of Passable Pedal Impulse Sealing Machine; high efficiency sealing working, easily operation, long sealing length.

It's widely used in the field of sealing working.

Operation:

1. Assemble according to the sketch map.
2. Power up the machine (Red light will lighted)
3. Put the film into the working table, then push the foot pedal to

- make machine working (Green light will lighted),
4. Try to get the suitable sealing effect by adjusting the heating time adjuster.
5. Loose the foot pedal after 3 Sec to get more well sealing effect.

Parameters:

Type	Power	Sealing Length	Warming Time	Weight
300	350W	300MM	0.2-2.5Sec	10KGS
400	450W	400MM	0.2-2.5Sec	11KGS
500	500W	500MM	0.2-2.5Sec	12KGS
600	620W	600MM	0.2-2.5Sec	13.5KGS
700	700W	700MM	0.2-2.5Sec	14.5KGS
800	800W	800MM	0.2-2.5Sec	15.5KGS
900	880W	900MM	0.2-2.5Sec	16.5KGS
1000	960W	1000MM	0.2-2.5Sec	17.5KGS