BAR&SECTION PUNCHING SHEAR PBS-9



MANUAL

USAGE

This product can be used to cut the low-carton shaped steel, round-steel, angle-steel, square-steel, strip-steel and sheet metal. It is especially suitable for building site machining repairing. And it is suitable for punching holes in plate made or low-carbon steel, copper, aluminum, plastic etc. With different punches and dies, you can make holes from dia. 3mm to 22mm or the same holes of special shape on plate from 0.5mm to 4.5mm thickness. This machine adopts welded steel plate construction. Light weight allows moving it easily. Operation is easy and simple. So it is especially suitable for the medium or small workshops and home-use.

Main technical specifications (mm):

| Model | PBS-9 | | | | | |
|------------------------|---------------|--------|---------|---------|---------|--|
| Round steel | 22mm | | | | | |
| Square Steel | 20mm | | | | | |
| Flat steel | 90x14mm | | | | | |
| Angle steel | 60x7mm | | | | | |
| Plate steel | 10mm | | | | | |
| T-steel | 60x7mm | | | | | |
| Max. punching capacity | 8.0mm | | | | | |
| Throat depth | | | 160mm | | | |
| Punch mold & die | 55x34x18mm | | | | | |
| Body packing size | 99x40x66cm | | | | | |
| Handle packing size | 124x3.3x7.4cm | | | | | |
| N.W/G.W | 99/115kg | | | | | |
| Thickness | 0.5-1.5 | | 1.5-2.5 | 2.5-3.5 | 3.5-5.0 | |
| Material | | | | | | |
| Aluminium | 2.5-20 | 3. | 0-20 | 5.0-20 | 8.0-20 | |
| Copper | 3.0-30 | 5. | 0-20 | 6.0-20 | 8.0-20 | |
| A3 carbon steel | 6.0-30 | 8.0-18 | | 10-17 | | |

NOTE

- 1. Before using this machine, read this manual carefully at first. Check the fastening screws of every part and see if they are loose, if loose, please tighten them.
- 2. Lubricate the sliding place usually.
- 3. Before shearing, the work-piece must be fastened in order to avoid harming.
- 4. Be sure not to put finger under the blade.
- 5. Keep ones balance, far away from the work-piece, in order to avoid harming.
- 6. Be care for the handle, in order to avoid harming. The strength of the handle is

different because the position of the spring is different.

7. Keep children far away from the machine.

OPERATION

- I. CUT STEEL PLATE, STRIP STEEL
- 1. Raise handle (46), make upper blade and down blade keeping a certain distance.
- 2. Put the steel plate on the down blade (33), ensure the suitable size, then tighten the handle (8), fix the work-piece with the plate (21), turn the handle (4) downward strongly.
- II. CUT ROUND AND SQUARE STEEL

Raise the handle (47), put the round (square) steel into the round (square) hole of the blade, and into the round (square) hole of the support plate (3), turn the handle (47) downward strongly.

III. CUT ANGLE AND T-STEEL

Raise the handle 47) put the work-piece into the groove (its shape is the same as the work-piece) and into the groove of support plate (3).

IV. There are two holes in the connecting plate (6), operator can select anyone according to the different position and strength.

MAINTAIN

1. Lubrication

Before using, apply some grease to the teeth, pour lubricating oil into the oil cup (14).

2. If not using the machine long time, smear blades with antirust oil.

PARTS LIST

| Item | Description | Qty | Item | Description | Qty |
|------|-----------------------|-----|------|------------------|-----|
| 1 | Body | 1 | 38 | Spring Pin | 4 |
| 2 | Bolt | 1 | 39 | Supporting Shaft | 1 |
| 3 | Support Plate | 1 | 40 | Left Spring | 2 |
| 4 | Washer | 9 | 41 | Screw | 1 |
| 5 | Nut | 7 | 42 | Down Blade | 1 |
| 6 | Connecting Plate | 2 | 43 | Shaft | 1 |
| 7 | Ring | 2 | 44 | Bolt | 1 |
| 8 | Handle | 1 | 45 | Arm | 1 |
| 9 | Screw | 1 | 46 | Handle | 1 |
| 10 | Sleeve | 1 | 47 | Handle Sleeve | 1 |
| 11 | Screw | 1 | 48 | Bolt | 1 |
| 12 | Bar | 1 | 49 | Washer | 1 |
| 13 | Plate | 1 | 50 | bar | 1 |
| 14 | Blade Base | 4 | 51 | Block | 1 |
| 15 | Oil Cup | 1 | 52 | Washer | 4 |
| 16 | Tooth Plate | 1 | 53 | Bolt | 2 |
| 17 | Shaft | 3 | 54 | Supporting plate | 1 |
| 18 | Washer | 1 | 55 | Washer | 2 |
| 19 | Moving Blade | 1 | 56 | Small shaft | 2 |
| 20 | Screw | 2 | 57 | Strength bar | 1 |
| 21 | Press Plate | 1 | 58 | Rack arm support | 1 |
| 22 | Support | 1 | 59 | Bolt | 2 |
| 23 | Bolt | 2 | 60 | Bolt | 1 |
| 24 | Shield | 1 | 61 | Punching die | 1 |
| 25 | Fixed Plate | 1 | 62 | Bolt | 2 |
| 26 | Moving Piece | 1 | 63 | Bolt | 2 |
| 27 | Bolt | 3 | 64 | Punching die set | 1 |
| 28 | Spring Washer | 5 | 65 | Bolt | 4 |
| 29 | Bolt | 4 | 66 | Punch | 1 |
| 30 | Adjustable Down Blade | 1 | 67 | Slid set | 1 |
| 31 | V-Upper Blade | 1 | 68 | Punch | 1 |
| 32 | Small Shaft | 2 | 69 | Pin | 1 |
| 33 | Upper Blade | 1 | 70 | Block | 1 |
| 34 | Bolt | 1 | 71 | Nut M16 | 2 |
| 35 | Right Spring | 2 | 72 | Supporting plate | 1 |
| 36 | Sleeve | 4 | 73 | Nut M20 | 3 |
| 37 | Screw Sleeve | 4 | | | |

ASSEMBLY DRAWING



