

Be careful!

The charger can only be used indoors.

Do not charge in confined space, direct sunlight or high temperature environment.

Do not connect the charger with no load (no battery connected) to the power supply.

If there is any abnormality in your charger: the indicator light flashes, the smell or the housing overheats, please stop charging immediately!

It is prohibited to disassemble and replace the charger parts by yourself, use the charger under high humidity and close to water, and use the charger under fire hazard conditions (if there is combustible gas / flammable substance vapor in the atmosphere).

Avoid leakage and battery case damage

Do not touch the charger contacts - this may cause electric shock.

If the charger fails, do not touch its housing - this may cause electric shock

Matching

1. Electric scooter
2. Charging
3. Description
4. A set of keys
5. Luggage rack
6. Mirror



S 8

USER 'S MANUAL

Product type: electric scooter

Battery type: lithium ion

Battery capacity: 25ah

Rated voltage: 60V

Charging time: 10 hours

Battery range when fully charged: up to 60km

Allowable maximum load: 200kg

Brake system: Hydraulic

Tire type: tubeless

Airborne computer with battery level indicator

Frame and wing color: color

Set up

Length: 194 cm

Height: 91cm

Ridge: 117 cm

Package size: 182 * 38 * 86cm

Tire size: 12 inches

Electric scooter weight: 81 kg

Packing weight: 90kg

Necessary warnings

Always obey the traffic rules.

Observe the speed mode and select the safe speed according to the road conditions

Please read the instructions before traveling. In order to drive the scooter safely, you must practice on the open ground. Make sure you have mastered the basic control principles and understand the speed capability of the scooter.

Don't let people who don't have the necessary skills drive scooters. Pay special attention to driving safety on wet snow roads. Avoid overspeed to high speed under difficult conditions.

Drive slowly over the uneven road and pay attention to the stones, sand and garbage that may fall under the wheels.

I always wear a helmet. Clothing should not interfere with movement and control. Flat shoes are recommended when riding a scooter.

Do not overload the electric scooter - the handling may be seriously deteriorated.

General recommendations for scooter management

It is allowed to control the scooter standing and sitting.

When riding standing, it is important to avoid sudden acceleration

Open the accelerator smoothly. When driving, try to sit in the center of the seat, so as to avoid front wheel unloading and steering wheel vibration.

Motion

Insert the key into the ignition lock and rotate clockwise until the first click. In this way, the power and battery indicators on the instrument panel will be on. The scooter is ready for the trip.

To turn on the headlights, turn the ignition key clockwise until the second click.